

Customer	<i>White Exploration</i>	Lease No.		Date	<i>1-13-12</i>
Lease	<i>Lonker</i>	Well #	<i>1</i>	Service Receipt	<i>171702608</i>
Casing	<i>5 1/2</i>	Depth	<i>4852</i>	County	<i>Barber</i>
Job Type	<i>Z 42 5 1/2 L.S.</i>	Formation		State	<i>Ks</i>
				Legal Description	<i>22 325 12W</i>

Pipe Data		Perforating Data		Cement Data
Casing size	Tubing Size	Shots/Ft		Lead
Depth	Depth	From	To	<i>See Callsheet</i>
Volume	Volume	From	To	
Max Press	Max Press	From	To	Tail in
Well Connection	Annulus Vol.	From	To	
Plug Depth	Packer Depth	From	To	

Time	Casing Pressure	Tubing Pressure	Bbls. Pumped	Rate	Service Log
<i>01:00</i>					<i>on loc. / Held Safety Meeting</i>
<i>02:45</i>					<i>Start Csg.</i>
<i>05:30</i>					<i>Csg on Bottom Cir. w/ Rig</i>
<i>07:40</i>	<i>3000</i>				<i>Test Pump + Lines</i>
<i>07:42</i>	<i>200</i>		<i>5</i>	<i>5</i>	<i>Start Fresh H₂O</i>
<i>07:43</i>	<i>250</i>		<i>12</i>	<i>5</i>	<i>Start Super Flush #</i>
<i>07:46</i>	<i>250</i>		<i>5</i>	<i>5</i>	<i>Start Fresh H₂O</i>
<i>07:47</i>	<i>350</i>		<i>57</i>	<i>6</i>	<i>Start Cmt 225sk @ 15"</i>
<i>07:59</i>					<i>Shutdown + Wash up</i>
<i>08:02</i>					<i>Drop Plug</i>
<i>08:03</i>	<i>100</i>		<i>0</i>	<i>6.5</i>	<i>Start Disp. w/ Fresh H₂O</i>
<i>08:03</i>					<i>Slow Rate</i>
<i>08:24</i>	<i>2600</i>		<i>115</i>	<i>6.5</i>	<i>Bump Plug</i>
<i>08:25</i>	<i>0</i>			<i>0</i>	<i>Release + ✓ flowback</i>
<i>08:25</i>					<i>Plug Held</i>
	<i>1160</i>				<i>Pressure Before Plug Landed</i>
					<i>Knock Loose + Hook up to 2"</i>
<i>09:47</i>	<i>100</i>		<i>5</i>	<i>2.5</i>	<i>Plug Mouse Hole w/ 20sk @ 15"</i>
<i>09:53</i>	<i>100</i>		<i>7</i>	<i>2.5</i>	<i>Plug Rat Hole w/ 30sk @ 15"</i>
<i>09:10</i>					<i>Knock Loose + Wash up</i>
<i>09:30</i>					<i>End Job</i>

Service Units	<i>19757</i>	<i>381171243</i>	<i>1996019918</i>		
Driver Names	<i>Cochran</i>	<i>Mendoza</i>	<i>J. Martinez</i>		

J. Bennett
Station Manager

M. Cochran
Cementer

Customer Representative