## D.S. & W. Well Servicing, Inc.

1822 24th Street Great Bend, KS 67530

# **Invoice**

Date	Invoice #
11/4/2010	68119

Bill To

Carmen Schmitt, Inc.

Carmen Schmitt

P.O. Box 47

Great Bend, KS 67530-0047

		Lease	Name	Terms	Due Date	
		Dorr #	<sup>‡</sup> 103	30 Days	12/4/2010	
ltem	Description	Qty	,	Rate	Amount	
Rig #23 MPPS Workover Head Stripper Rubber Solvent Thread Dope Weight Indicator	Hess #1058-120 Double Drum Pole - #23 Mud Pump & Power Swivel Workover Head Stripper Rubber - USED Cleaning Solvent Thread Dope Weight Indicator		34 6 1 0.5 4 5	197.00 165.00 110.00 131.05 5.18 17.50 55.00	6,698.007 990.007 110.007 65.537 20.727 87.507 55.007	
Thank You  620-793-5838 Office 620-793-5860 Fax			Subtotal \$8,			
			Sales Tax (6.3%)		\$505.69	
			Total \$8,533			

**Balance Due** 

\$8,532.44

1945) 65 th 2010

## D.S.&W. WELL SERVICING, INC.

1822 24th Street **Great Bend, KS 67530** 

	Date:	11/04/10	_			Lease:	Dorr		
Com	pany:	Carmen Schmitt	, Inc.			Well:	#103 - PI	ua Well	•
			eat Bend, KS 6753	30	Inv		68119	<u> </u>	<del>, ,</del>
		· · · · · · · ·	-	VELL PULLING REPOR	•	,			
	-	PULLED			<u> </u>	•	R	UN	
JTS.	FT.	DESC	RIPTION	<b>EQUIPMENT</b>	JTS.	FT.		DESCRIF	PTION
		2-7/8"		MUD ANCHOR				•	
400		2-7/8"		SEATING NIPPLE					
106		2-7/8" 2-7/8"		TUBING					
1		2-7/8"		TUBING SUBS TUBING SUBS	<del> </del>				
<del>'</del> '}	1	2-110		STRAINER GAS ANCHOR				<u>-</u>	
		2-1/2"x2"x12' R\	ΝT	PUMP					
42		1"		RODS					
54		7/8"		RODS					
32		3/4"		RODS					
4		7/8"		RODS					
1		1" 1"		ROD SUBS					
1		7/8"		ROD SUBS					
<del>'</del>		1-1/2"		POLISH ROD	-				
		1-3/4"		LINER	1				
			Pole Rig #23, open MP&PS - 6 hrs @	rator & crew of 2 men \$165.00	34.0	hrs @	\$ 197.00	\$ \$	6,698.00 990.00
			Workover Head	<u> </u>				\$	110.00
			5-1/2" x 2-7/8" Str	ipper Rubber - USED5 @	\$131.0	5		\$	65.53
		<u>.</u>	Solvent - 4 gallons	s @ \$5.18			· · · · · · · · · · · · · · · · · · ·	\$	20.72
			Thread Dope - 5 t	rips @ \$17.50				\$	87.50
			Weight Indicator	<del></del>				\$	55.00
			Sub-Total			•		\$	8,026.75
			Sales Tax - Rooks	S County 6.3%				\$	505.69
			Total Due			_		\$	8,532.44
<b>11/04/</b> 1 down.	10 - 3 F	Rig hrs - M.I.R.U.	Discuss daily safe	ty issues. Un-hang well. Un	-seat p	ump - p	oull out w/2	2' polish ı	rod. Shut
	10 - 9.5	Rig hrs - Drove	to location. Discus	s daily safety issues. Pull ou	ıt w/2'.	4' x 1" s	ubs. 42 - 1	l". 54 - 7/8	8". 32 <i>-</i> 3/4".
				ig over to pull tubing. Un-page					
				Break out production head.					
				jts in the hole. Trip back out					
_		· · · · · · · · · · · · · · · · · · ·							ICING, INC.
Date V		11/04/10	Date Work Completed	11/11/10		Ву	Danny	Schulz	

# D.S.&W. WELL SERVICING, INC.

1822 24th Street **Great Bend, KS 67530** 

Date: 11/04/10	Lease:	Dorr
Company: Carmen Schmitt, Inc.	Well:	#103 - Plug Well
Address: P.O. Box 47, Great Bend, KS 67530	Invoice #:	68119
CONTINUATION SHEET	#1	
11/08/10 - 2 MP&PS hrs - Haul MP&PS to location.		
11/09/10 - 9 Rig hrs & 4 MP&PS hrs - Drove to location. Discuss daily safety	issues. Run in	w/4-7/8" bit & tubing - tally in.
Tag @ 1950'. Hook up MP&PS. Break circulation. Try to wash down - acted	d like we were dr	illing on casing. Lay down PS.
Rack out MP. Trip out w/tubing & bit. Run in w/tubing open ended. Ran in 5	jts past bad spo	ot. Shut down.
11/10/10 - 10.5 Rig hrs - Drove to location. Discuss daily safety issues. Trip	out w/tubing. R	un in w/4' - 2-3/8" sub, swedge,
4-1/2" slim-hole collar, swedge & 2-7/8" tubing. Ran tubing 4 jts past bad spo	ot - stacked out.	Pulled 40,000# over string
weight to get loose. Pull 5 jts tubing. Wait on orders. Trip out w/tubing. Wa	it on & rig up log	gers. Perf @ 790', 1260'. Tear
down loggers. Run in w/tubing to 3000'. Hook up cementers to plug well. Pu	ump cement @ 3	3000', 1903', 782' - circulate
cement to surface. Pull tubing rest of way out. Break out working head. Top	off w/cement.	Shut down.
11/11/10 - 2 Rig hrs - Drove to location. Discuss daily safety issues. Rig dov	wn. Clean up loc	eation.
<del></del>		
<u> </u>		
	<del></del>	
		<u></u>
		<u>.                                    </u>
		<del></del>
	<u> </u>	<del></del>
		<del></del>

**D.S. & W. Well Servicing, Inc.**Telephone (620) 793-5838 - 1822 24th Street - Great Bend, KS 67530

DAILY WORKOVER REPORT

Scraper & tubing. Tubing stacked out 62, its in the hole. Trip out w/tubing, scraper, & bit. Shut down  Oty Special Tools / Supplies Used	-2010
Operator: Danny S, Floor Hand: Victor S, Floor Hand: Victor S, Floor Hand: Wicker S, Floor Hand: Steve H, Floor Hand: MTRU, DDST. Un-hang well. Unseat pump, pull out w/22 PR, Shu  Oty Special Tools / Supplies Used  I trip dape Date: 11-5-10 Operator: Danny S, Floor Hand: Victor S, Floor Hand: Victor S, Floor Hand: Victor S, Floor Hand: Steve H. Floor Hand: Steve H	<del></del> -
Date: 11-4-10 Operator: Danny S. Floor Hand: Victor S. Floor Hand: Steve H. Floor Hand:  Oty Special Tools / Supplies Used  Other Hand: Unseat pump, pull out w/22 PR. Shu Floor Hand: Victor S. Floor Hand: Victor S. Floor Hand: Steve H. Floor Hand: Steve H. Floor Hand: Steve H. Floor Hand: Steve H. Floor Hand: Work Performed: DTT, DDST. Pull out w/2-4-1" subs 42-1", 54-78" 32-34", 4-78" subs 24:x2" x12" RwT. Rig over to pull tubing. Unpack well head Release AC, Trip out w/8' 10'-278" subs 106; ts 274" tubing, SN. AC, Break out pund head Put on working head. Run in w/478" bit, ca scraper & tubing, Tubing, stacked out 62; its in the hele. Trip is out w/tubing, scraper, & bit. Shut down	
Place Hand: Victor S. Floor Hand: Steve H. Floor Hand: Steve H. Floor Hand: Steve H. Floor Hand: MTRU, DDST. Un-brang well, Unseat pump, pull out w/22° PR, Shu  I trip dape Date: 11-5-10 Operator: Danny S. I Working head Floor Hand: Victor S. Floor Hand: Steve H. Floor Hand: Steve H. Floor Hand: Mork Performed: DTT, DDST. Pull out w/2-4-1" subs 42-1, 54-78", 32-34", 4-78" r. 3-78" sub 32x2" x12" RWT. Rig over to pull twing. Unpack well head Release AC, Trip out w/8" 10-278" subs 106'sts 27" twing SN, AC, Break out pood head Put on working head. Run in w/4" bit, ca scraper & twing. Tubing stacked out 62 jts in the hole. Trip out w/twing, scraper, & bit. Shut down  Oty Special Tools / Supplies Used	HRS.
Relasse AC, Trip out w/8-10-278" subs 106 ts 218" tubing 5N, AC, Break out prod. head. Put all tubing, Tubing 5tacked out 62 its in the hole. Trip out w/tubing, scraper, 5 bit. Shut down	3 /
Active Performed: MTRU, DDST. Un-hang well. Unseaf pump, pull out w/22 PR. Shu  At the dape Date: 11-5-10 Operator: Danny S.  Floor Hand: Victor S.  Floor Hand: Victor S.  Floor Hand: Steve H.  Floor Hand:  Nork Performed: DTL, DDST. Pull out w/2-4-1" subs 42-1," 54-78," 32-74," 4-78" r.  21-78" sub, 2'2"x2" x12" RwT. Rig over to pull tubing. Ungack well head  Relasc AC, Trip out w/8'-10'-278" subs 106; ts 274" tubing, SN, AC,  Break out prod. head. Put on working head. Run in w/478" bit ca  scraper & tubing. Tubing. stacked out 62; ts in the hole. Trip out w/tubing, scraper, & bit. Shut down	3 ~
Oty Special Tools / Supplies Used  Other Performed: MTRU, DDST. Un-hang well. Unseat pump, pull out w/22 PR. Shu  Other Special Tools / Supplies Used	3
Oty Special Tools / Supplies Used  I trip dope  Date: 11-5-10 Operator: Danny S.  Hoor Hand: Victor S.  Floor Hand: Steve H.  Floor Hand:  Nork Performed: DTI, DDST. Pull out w/2-4-1" subs 42-1", 54-78", 32-34", 4-78", 21-78" sub, 2½x2"x12" RwT. Rig over to pull tribing. Unpack well head Release AC, Trip out w/8'-10'-278" subs 106; ts 278" tubing SN. AC, Break out prod. head. Put on working head. Run in w/4"8" bit ca scraper? tubing, Tubing stacked out 62; its in the hole. Trip out w/tubing, scraper, & bit. Shut down	<u> </u>
Oty Special Tools / Supplies Used  I trip dope  Date: 11-5-10 Operator: Danny S.  Floor Hand: Victor S.  Floor Hand: Steve H.  Floor Hand: Steve H.  Floor Hand:  Break out prod. head Put w/2-4-1"subs 42-1", 54-78", 32-34", 4-78", 2-78"subs 2'2"x2"x1z' RwT. Rig over to pull tribing. Unpack well head Release AC, Trip out w/8'-10'-278"subs 106", ts. 278" tribing SN. AC, Break out prod. head Put on working head. Run in w/4"8" bit ca scraper? tubing. Tubing stacked out 62 its in the hole. Trip out w/tubing, scraper, & bit. Shut down  Out Special Tools / Supplies Used	+ day
I trip dope  Date: 11-5-10 Operator: Danny 5,  Floor Hand: Victor 5.  Floor Hand: Steve H.  Floor Hand:  Work Performed: DTL, DDSI, Pull out w/2-4-1" subs 42-1", 54-78", 32-3/4", 4-78",  2'-78" sub, 2'2"x2" x12" RwT. Rig over to pull tubing. Unpack well head  Release AC, Trip out w/8'-10'-278" subs 106; its 278" tubing 5N, AC,  Break out prod. head. Put on working head, Run in w/4"8" bit, ca  scraper? tubing. Tubing stacked out 62 its in the hole. Trip out w/tubing, scraper, & bit. Shut down	
I trip dope  Date: 11-5-10 Operator: Danny 5,  Floor Hand: Victor 5.  Floor Hand: Steve H.  Floor Hand:  Work Performed: DTL, DDSI, Pull out w/2-4-1" subs 42-1", 54-78", 32-3/4", 4-78",  2'-78" sub, 2'2"x2" x12" RwT. Rig over to pull tubing. Unpack well head  Release AC, Trip out w/8'-10'-278" subs 106; its 278" tubing 5N, AC,  Break out prod. head. Put on working head, Run in w/4"8" bit, ca  scraper? tubing. Tubing stacked out 62 its in the hole. Trip out w/tubing, scraper, & bit. Shut down	
I trip dope  Date: 11-5-10 Operator: Danny 5,  Floor Hand: Victor 5.  Floor Hand: Steve H.  Floor Hand:  Work Performed: DTL, DDSI, Pull out w/2-4-1" subs 42-1", 54-78", 32-3/4", 4-78",  2'-78" sub, 2'2'x2" x12' RwT. Rig over to pull tubing. Unpack well head  Re loase AC, Trip out w/8'-10'-278" subs 106; its 2 % tubing 5N, AC,  Break out prod. head. Put on working head. Run in w/4"8" bit, ca  scraper? tubing. Tubing stacked out 62 its in the hole. Trip out w/tubing, scraper, & bit. Shut down	
I trip dope  Date: 11-5-10 Operator: Danny 5,  Floor Hand: Victor 5.  Floor Hand: Steve H.  Floor Hand:  Nork Performed: DTL, DDSI, Pull out w/2-4-1"subs 42-1", 54-78", 32-3/4", 4-78",  2'-7/8"sub, 2'2"x2"x12' RwT. Rig over to pull tubing. Unpack well head  Re loase AC, Trip out w/8'-10'-27/8"subs 106; its 2 1/4" tubing 5N, AC,  Break out prod. head. Put on working head. Run in w/4"/8" bit, ca  scraper? tubing. Tubing stacked out 62 its in the hole. Trip out w/tubing, scraper, & bit. Shut down	
I trip dope  Date: 11-5-10 Operator: Danny 5,  Floor Hand: Victor 5.  Floor Hand: Steve H.  Floor Hand:  Nork Performed: DTL, DDSI, Pull out w/2-4-1"subs 42-1", 54-78", 32-3/4", 4-78",  2'-7/8"sub, 2'2"x2"x12' RwT. Rig over to pull tubing. Unpack well head  Re loase AC, Trip out w/8'-10'-27/8"subs 106; its 2 1/4" tubing 5N, AC,  Break out prod. head. Put on working head. Run in w/4"/8" bit, ca  scraper? tubing. Tubing stacked out 62 its in the hole. Trip out w/tubing, scraper, & bit. Shut down	
I trip dope  Date: 11-5-10 Operator: Danny 5,  Floor Hand: Victor 5.  Floor Hand: Steve H.  Floor Hand:  Nork Performed: DTI, DDSI, Pull out w/2-4-1"subs 42-1", 54-78", 32-3/4", 4-78", 2'-7/8"sub, 2'2"x2"x12" RwT. Rig over to pull tubing. Unpack well head  Re loase. AC, Trip out w/8'-10'-27/8"subs 106; its 2 1/8" tubing 5N, AC,  Break out prod. head. Put on working head. Run in w/4"/8" bit, ca  scraper? tubing. Tubing stacked out 62; its in the hole. Trip out w/tubing, scraper, & bit. Shut down	
Floor Hand: Victor 5. Floor Hand: Steve H.  Floor Hand:  Work Performed: DTT. DDST. Pull out w/2-4-1" subs 42-1," 54-78" 32-3/4", 4-78" r.  2'-7/8" subs 2'2'x2"x12' RwT. Rig over to pull tubing. Unpack well head  Release AC, Trip out w/8'-10'-27/8" subs 106; ts 2 1/4" tubing, 5N, AC,  Break out prod. head. Put on working head. Run in w/47/8" bit, ca  scraper ? tubing. Tubing. stacked out 62; its in the hole. Trip out w/tubing, scraper, Ebit. Shut down	HRS.
Floor Hand: Steve H.  Floor Hand:  Work Performed: DTI, DDSI. Pull out w/2-4-1"subs 42-1," 54-78" 32-3/4", 4-78" r 2'-78"sub 2'2"x12" RWT. Rig over to pull tubing. Unpack well head Release AC, Trip out w/8'-10'-278" subs, 106; ts, 2 % "tubing, 5N, AC, Break out prod. head. Put on working head. Run in w/4"8" bit, ca scraper & tubing. Tubing stacked out 62; ts in the hole. Trip is out w/tubing, scraper, & bit. Shut down  Oty Special Tools / Supplies Used	9/2
Nork Performed: DTT, DDST. Pull out w/2-4-1"subs, 42-1," 54-78", 32-3/4", 4-78", 2'-78" sub, 2'2"x2"x12' RWT. Rig over to pull tubing. Unpack well head Release. AC, Trip out w/8-10'-278" subs, 106; ts, 278" tubing, 5N, AC, Break out prod. head. Put on working head. Run in w/478" bit, ca scraper & tubing. Tubing, stacked out 62; its in the hole. Trip out w/tubing, scraper, & bit. Shut down  Out Special Tools / Supplies Used	9/2
Nork Performed: DTI, DDSI, Pull out w/2-4-1"subs, 42-1," 54-78", 32-3/4", 4-78", 2'-7/8"sub, 2'2'x2"x12' RwT. Rig over to pull tubing. Unpack well head Release AC, Trip out w/8'-10'-278"subs, 106; ts 2 1/4" tubing, 5N, AC, Break out prod. head. Put on working head. Run in w/4"/8" bit, ca scraper? tubing. Tubing stacked out 62; ts in the hole. Trip out w/tubing, scraper, & bit. Shut down	91/2
2'-78" sub 2'2x2"x12' RWT. Rig over to pull tubing. Unpack well head Release AC, Trip out w/8'-10'-278" subs 106; ts 278" tubing 5N, AC, Break out prod. head. Put on working head. Run in w/4"8" bit, ca scraper ? tubing. Tubing stacked out 62; its in the hole. Trip out w/tubing, scraper, & bit. Shut down	
2'-78" sub 2'2x2"x12' RWT. Rig over to pull tubing. Unpack well head Release AC, Trip out w/8'-10'-278" subs 106; ts 278" tubing 5N, AC, Break out prod. head. Put on working head. Run in w/4"8" bit, ca scraper ? tubing. Tubing stacked out 62; ts in the hole. Trip out w/tubing, scraper, & bit. Shut down  Out Special Tools / Supplies Used	ods
Release AC, Trip out w/8-10'-278" subs 106; ts 278" tubing 5N, AC, Break out prod. head. Put on working head. Run in w/4"8" bit, ca scraper & tubing. Tubing stacked out 62; ts in the hole. Trip out w/tubing, scraper, & bit. Shut down  Out Special Tools / Supplies Used	
Break out prod. head. Put on working head. Run in w/4 1/8" bit, ca scraper & tubing. Tubing stacked out 62; its in the hole. Trip out w/tubing, scraper, & bit. Shut down  On Special Tools / Supplies Used	,
Scraper ? tubing. Tubing stacked out 62; its in the hole. Trip	Sing
Out w/tubing, scraper, & bit. Shut down  Oty Special Tools / Supplies Used	1 Z
Qty Special Tools / Supplies Used	-
1 / / / .	
1 / / / .	
2 / Land And Date: 11 Q in Date: 11 Q	HRS.
2 trips dope Date: /1-9-10 Operator: Danny S.	9.
1 used 51/2 x 21/8 strianing rubber Floor Hand: Victor S.	91
MP & P.5 Floor Hand: Steve H.	9.
2 pal solvent	
Not PACT R 1/47/6" 61/5 4.61 - + 1/1 T - 6	1950
work Performed. 27 E 12 12 14 14 14 14 14 14 14 14 14 14 14 14 14	1. V.
We were drilling on casing, Lay down PS. Rack out MP. Trie	and
we were drilling on casing, Lay down PS. Kack out MP. Trip	<u> </u>
WI TUDING & DIT. NUM IN WI TUDING Offen ENDIO. Kan in 5,+5 past	Dad
spot. Thut down,	

**D.S. & W. Well Servicing, Inc.**Telephone (620) 793-5838 - 1822 24th Street - Great Bend, KS 67530

DAILY WORKOVER REPORT

Company	y <u>Car</u>	men Sc	hmitt		Date	11-10,11-20	10
Rig#	23_	Lease	Dorc	Well#	City		
Section_		Township_	Range	County_ <u>Rooks</u>	State_	<u> </u>	<del></del>
Qty	Special Too	ls / Supplies Used					HRS.
2	trips d	oft	Date: 11-10-10	Operator: Danny	<u>.                                    </u>		10/2×
29	ral solu	vent		Floor Hand: Victor	5		10/2
	<del></del>		···	Floor Hand: Steve	4		10/2
				Floor Hand:			
Work Perfori	med: DTL	DOST.	Trip out w/tubi	ng. Run in w/4-2	3/8"506	Swedge 4	1/2"
Slin-	-hole co	llar SWE	dge & 21/8" tulin	g. Ran tubing 4	45 Das	+ bad spot	
,	Ked ou		1 40,000 over		get 1	4.,	5:43
tu61.	نولايا الع			w/ fubing, Wait on	<i>7</i> '	· · · · · · · · · · · · · · · · · · ·	- V
	,		Tear down log		1 1	1	
	comente	,	. 4 /	cement @ 3000;	1903	1 1	Cem
<del></del>		- , <i>T</i> -		Break out working 1		, , ,	una int
Qty		ls / Supplies Used					HRS.
			Date: //-//-/0	Operator: Danny 5			21
				Floor Hand: Wictor 5.			2 V
				Floor Hand: Steve H	_		21
				Floor Hand:			
			,				
Qty	Special Too	ols / Supplies Used					HRS.
			Date:	Operator:			
				Floor Hand:		<del></del>	
				Floor Hand:			
				Floor Hand:			
Work Perfor	rmed:						
			•				
			- <u>-</u> -				
						<del> </del>	
					-		