



**TREATMENT REPORT**

Acid Stage No. \_\_\_\_\_

Date 6/18/2014 District G.B. F.O. No. CAQ199  
 Company Mark Connell  
 Well Name & No. S. Behnke OWWO  
 Location \_\_\_\_\_ Field \_\_\_\_\_  
 County Rice State KS  
 Casing: Size 5.5" Type & Wt. \_\_\_\_\_ Set at \_\_\_\_\_ ft.  
 Formation: \_\_\_\_\_ Perf. \_\_\_\_\_ to \_\_\_\_\_  
 Formation: \_\_\_\_\_ Perf. \_\_\_\_\_ to \_\_\_\_\_  
 Formation: \_\_\_\_\_ Perf. \_\_\_\_\_ to \_\_\_\_\_  
 Liner: Size \_\_\_\_\_ Type & Wt. \_\_\_\_\_ Top at \_\_\_\_\_ ft. Bottom at \_\_\_\_\_ ft.  
 Cemented:  Perforated from \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Tubing: Size & Wt. 2.5" Spung at \_\_\_\_\_ ft.  
 Perforated from \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Open Hole Size \_\_\_\_\_ T.D. \_\_\_\_\_ ft. P.B. to \_\_\_\_\_ ft.

Type Treatment: Amt. Type Fluid Sand Size Pounds of Sand  
 Blowdown \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 Flush \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 Treated from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. No. ft. 0  
 from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. No. ft. 0  
 from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. No. ft. 0  
 Actual Volume of Oil / Water to Load Hole: \_\_\_\_\_ Bbl./Gal.  
 Pump Trucks No. Used: Std. 320 Sp. \_\_\_\_\_ Twin \_\_\_\_\_  
 Auxiliary Equipment \_\_\_\_\_ 327  
 Personnel Nathan Greg Jordan  
 Auxiliary Tools \_\_\_\_\_  
 Plugging or Sealing Materials: Type \_\_\_\_\_ Gals. \_\_\_\_\_ lb.

Company Representative Mark C. Treater Nathan W.

TIME a.m./p.m.	PRESSURES		Total Fluid Pumped	REMARKS
	Tubing	Casing		
11:00	2.5"	5.5"		On Location.
				Plug-680'
				Port Collar-345'
				Set RBP at 680' Spot 2sks Sand. Pull tubing.
				Run in hole port collar opening tool. Isolate port collar at 345'
				Pressure up well to 500# Open port collar.
				Break circulation with water.
				Mix 210sks. Common. Circulated cement to surface.
2:10				Close port collar and pressure up to 500# Held.
				Run 3jts. And circulate hole clean.
				Pull port collar tool and run in to pull plug.
				Circulate sand off plug and pull out of hole.
				Thank You!
				Nathan W.