

## TREATMENT REPORT

		Acid 3t	age NO.	
		*	1 Size Pour	ds of Sand
		***************************************		
	Bbl./Gal.			
Flush	Bbl./Gal.			
Treated from	ft. to		ft. No. ft.	0
t. from	ft. to		ft. No. ft.	0
from	ft. to		ft. No. ft.	0
Actual Volume of Oil / Water t	o Load Hole:			Bbl./Gal.
t. Pump Trucks. No. Used:	Std. 365	Sp	Twin	
t. Auxiliary Equipment				
Personnel Nathan-Eddy-Aaron				
ft. Auxiliary Tools				
Plugging or Sealing Materials:	Туре			
ft.			Gals.	lb.
	Flush Treated from ft. from from Actual Volume of Oil / Water t  ft. Pump Trucks. No. Used: ft. Auxiliary Equipment ft. Personnel Nathan-Eddy-A ft. Auxiliary Tools	Bkdown Bbl./Gal. Bbl./Gal. Bbl./Gal. Bbl./Gal. Bbl./Gal. Bbl./Gal. Flush Bbl./Gal.  Treated from ft. to ft. to from ft. to ft. to Actual Volume of Oil / Water to Load Hole:  ft. Pump Trucks. No. Used: Std. 365 ft. Auxiliary Equipment ft. Personnel Nathan-Eddy-Aaron ft. Auxiliary Tools Plugging or Sealing Materials: Type	Type Treatment: Amt. Type Fluid Sand Bkdown Bbi./Gal. Bbi./Gal. Bbi./Gal. Bbi./Gal. Bbi./Gal.  Flush Bbi./Gal.  Treated from ft. to from ft. to from ft. to Actual Volume of Oil / Water to Load Hole:  ft. Pump Trucks. No. Used: Std. 365 Sp. ft. Auxiliary Equipment ft. Personnel Nathan-Eddy-Aaron ft. Auxiliary Tools Plugging or Sealing Materials: Type	Bkdown   Bbl./Gal.   Bbl./Gal.   Bbl./Gal.   Bbl./Gal.   Bbl./Gal.   Bbl./Gal.   Bbl./Gal.   Bbl./Gal.   Bbl./Gal.   Flush   Bbl./Gal.   Treated from   ft. to   ft. No. ft.   from   ft. to   ft. No. ft.   from   ft. to   ft. No. ft.   Actual Volume of Oil / Water to Load Hole:   Fump Trucks. No. Used: Std.   365   Sp.   Twin   ft.   Auxiliary Equipment   ft.   Pump Trucks.   No. Used: Std.   365   Sp.   Twin   ft.   Auxiliary Equipment   Fersonnel   Nathan-Eddy-Aaron   ft.   Auxiliary Tools   Plugging or Sealing Materials:   Type   T

TIME a.m./p.m. 9:00 2	PRE	PRESSURES				
	Tubing	Casing	Total Fluid Pumped	REMARKS		
	2" 5.5"		On Location. Rig trying to rip pipe lose. Could not get lose. Wait on			
				logger to shoot pipe off. Shot twice and did not come free. Rig up to		
				shoot perf holes.		
				Spot 50sks Common 3% C.C. at 850' Wait 1 hour. Did not tag plug.		
				Spot 50sks Common 3% C.C. at 850' Wait 1 hour. Tag plug at 500'		
				Pull tubing out and tie on casing. Mix 160sks and circulated cement to		
				surface out annulus.		
				Shut in.		
				Thank You!		
				Nathan W.		
***************************************						