

TREATMENT REPORT

Acid Stage No. RT

Date: 10/26/19 District: Binger F. O. No. _____
 Company: Te Pa Oil & Gas
 Well Name & No.: Diana #1
 Location: _____ Field: _____
 County: McPherson State: Ks

Type Treatment: Amt. _____ Type Fluid _____ Sand Size _____ Pounds of Sand _____
 Bkdown _____ Bbl./Gal. _____
 _____ Bbl./Gal. _____
 _____ Bbl./Gal. _____
 _____ Bbl./Gal. _____
 Flush _____ Bbl./Gal. _____
 Treated from _____ ft. to _____ ft. No. ft. _____
 from _____ ft. to _____ ft. No. ft. _____
 from _____ ft. to _____ ft. No. ft. _____

Casing: Size _____ Type & Wt. _____ Set at _____ ft.
 Formation: _____ Perf. _____ to _____
 Formation: _____ Perf. _____ to _____
 Formation: _____ Perf. _____ to _____
 Liner: Size _____ Type & Wt. _____ Top at _____ ft. Bottom at _____ ft.
 Cemented: Yes/No. Perforated from _____ ft. to _____ ft.
 Tubing: Size & Wt. _____ Swung at _____ ft.
 Perforated from _____ ft. to _____ ft.
 Open Hole Size _____ T.D. _____ ft. P.B. to _____ ft.

Actual Volume of Oil/Water to Load Hole: _____ Bbl./Gal.
 Pump Trucks No. Used: Std. 323 8p. _____ Twin _____
 Auxiliary Equipment Bulk 302
 Packer: _____ Set at _____ ft.
 Auxiliary Tools _____
 Plugging or Sealing Materials: Type 50 sack Class A Cem Both plug
145 sack 60-40-4⁰⁰ (Gal. Top plug) lb.

Company Representative _____ Treater: [Signature]

TIME a.m. / p.m.	PRESSURES		Total Fluid Pumped	REMARKS
	Tubing	Casing		
:				Tub @ 2815'
8:45				On 1000 psi ISA Run up to pump plugs - mix up 4 bags CC in 8 BBL's water
9:05			0	Start mix go down hole 6.4 sack Slurry Class A Cem
:			15 BBL	50 sack HOT plug any wash up Down hole
:			23 BBL	Displace cement to 2800' let fall rest way out
:				Pull tub out Run 3/4" to 250'
:				Start to hook up 3/4" tub collar broke off
:				& let pipe go down hole & Run had to go
:				get more 3/4" pipe & Run down surface
11:30			0	3/4" tub @ 250' Tie in - start mix go
:	600 #			down hole. 5.3 sack Slurry 3/4" REM @ 600'
12:20	700 #		31 BBL	105 sacks 60-40-4 ⁰⁰ Poz any in surface & start
:				full start lay down 3/4" tub & pulled pipe
:				through plug
:				Tie in 3/4" tub inside 5 1/2 @ 250'
:				Mix & go down hole: 30 sacks 60-40-4 ⁰⁰ Poz
:				Casey pull lay tub down & top of 10 sacks
:				Total on surface plug 145 sacks
:				Washup pack up & left location