

NELSON REMEDIAL WORK POSSIBILITIES

10/27/97

<u>Well No.</u>	<u>Gross Sand</u>	<u>Net Sand</u>	<u>Floodable Sand</u>	<u>Perfs.</u>
RW-13 (B-2)	19.0	5.0	3.8	671-74 & 677-80
(B-3)	17.0	0	0 (Black Sand)	683-89 & 692-98

Seating Nipple: 681' Casing: 2 7/8" Logger T.D.: 726'
Fraced: 1800# sand, 50 bbls. water, 26 ball sealers

Recommendations:

- 1) Using string 1", wash to 710-715 until returns are clean.
 - 2) Pull 1", shut-in overnight to let debris settle.
 - 3) Isolate B-2 and B-3 with packer or seat 1" in seating nipple. Circulate down 1" to check effectiveness of packer.
 - 4) Seal wellhead and inject into B-2 through annulus.
- OR:** use Faith Drilling equipment; blow hole clean with air; go to Step 2 above.