



TUNGSTEN CARBIDE INSERT

*CODE OF BIT CONDITION

TOOTH DULLNESS

(General Examination):

T-2.....	tooth height	2/8 gone
T-4.....	tooth height	4/8 gone
T-6.....	tooth height	6/8 gone
T-8.....	tooth height	8/8 gone

(If any ONE row has a majority of teeth broken, add the letters "BT").

BEARING CONDITION

(Check the worst Cone).

B-2.....Tight
B-4.....Medium
B-6.....Loose
B-8.....Locked or gone

BIT GAGE

I in gage
O out of gage
(If out of gage, follow the "O" with
the amount out of under gage in frac-
tions of inches).

Example #1 T2 B4 I
(Teeth 1/4 gone, Bearing Medium,
Bit in gage).

Example #2 T6 BT B6 O 1/2
(Teeth 6/8 gone, Broken Teeth,
Bearing Loose and bit out of gage
1/2 inch).

*As adopted AAODC Houston

For Further Information Write or Wire

Sii SMITH TOOL

Division of Smith International, Inc.

P.O. BOX C-19511

IRVINE, CALIFORNIA 92713
TEL: (714) 540-7010 • TELEX: 6-74575

**Branches in all principal oil centers
in the United States and Canada**

**YOUR
SMITH
REP.**

[illegible]