STATE OF KANSAS STATE CORPORATION COMMISSION


15-6

Q

Give All information Completely Make Required Affidavit Mail or Deliver Report to: Conservation Division State Corporation Commission 800 Bitting Bullding Wichita, Kansas

WELL PLUGGING RECORD

NORTH	Lease Ov Lease Na	as "NE/CNW¼SW½ vner The Derby	Oil Compa	any		*****************************
	O Lease Na	Th. *				
	l l	ame Pierce				Well No. 3
	Office Ad	ldress 1122 West	Douglas,	Wichita, Ka	ansas I wali	
	Characte	r of Well (completed	as Oil, Gas o	r Dry Hole)	т метт	6 –
1 1 1		ion for plugging filed				
	Applicati	on for plugging appro-	ved	***************************************	3 -	12 - 19
	Plugging	commenced		***************************************	4 -	10 - 19
1 ! !		completed				16 - 19
	Reason f	or abandonment of w	ell or produci	ng formationDe	epletion of	Arbuckle.
	If a prod	lucing well is abandon	ed, date of la	st production		19
Locate well correctly on abo Section Plat		mission obtained from Yes				
Name of Conservation Agent wh		of this well El	don Petty	·····································		***************************************
Producing formation Arbuc	kle	Depth to top374	A. Botto	m′	Total Depth of W	7ell 376 1 T
Show depth and thickness of all					zour zopur or v	C11
OIL, GAS OR WATER REC						NATUR PROPE
	JORDS					CASING RECORI
Formation	Content	From	То	Size	Put In	Pulled Out
Arbuckle	Oi.1			4 1/2"	37451	3118:
	l		1	1	1	
		,				
			1		1 .	
		1	1		I I	
feet for each	Filled hole off at 3118'. cement at both 250'. Set re	with chat to 3 Pulled pipe ttom. Finisher	735! Sho and put d mudding dumped 1	t pipe 4 sacks of hole to 5 sacks of		
feet for each	Filled hole roff at 3118'. cement at bot 250'. Set rocement at 250	with chat to 3. Pulled pipe	735. Sho and put d mudding dumped 1 le to top	t pipe 4 sacks of 6 hole to 5 sacks of and put		
feet for each	Filled hole moff at 3118' cement at bot 250'. Set recement at 250 lo sacks of company of the sacks of the s	with chat to 3 Pulled pipe ttom. Finishe ock bridge and 1. Mudded ho cement at surf	735! Sho and put d mudding dumped 1 le to top	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole moff at 3118. cement at both 250. Set recement at 250 lo sacks of cement at 250 lo s	with chat to 3 Pulled pipe ttom. Finishe ock bridge and O'. Mudded ho cement at surf	735! Sho and put d mudding dumped l le to top	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole roff at 3118'. cement at bot 250'. Set rocement at 250 10 sacks of contract at 250 10 sacks of contrac	with chat to 3 Pulled pipe ttom. Finishe ock bridge and 1. Mudded ho cement at surf	735! Sho and put d mudding dumped 1 le to top ace.	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole roff at 3118'. cement at bot 250'. Set rocement at 250 10 sacks of c	with chat to 3 Pulled pipe ttom. Finisher ock bridge and O'. Mudded ho cement at surf	735! Sho and put dumped 1 le to top ace.	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole roff at 3118'. cement at bot 250'. Set rocement at 250 10 sacks of c	with chat to 3 Pulled pipe ttom. Finishe ock bridge and O'. Mudded ho cement at surf	735! Sho and put dumped 1 le to top ace.	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole moff at 3118' cement at bot 250'. Set recement at 250 lo sacks of company of the sacks of the s	with chat to 3 Pulled pipe ttom. Finishe ock bridge and O'. Mudded ho cement at surf	735! Sho and put d mudding dumped l le to top ace.	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole moff at 3118' cement at bot 250'. Set recement at 250 lo sacks of company of the sacks of the s	with chat to 3 Pulled pipe ttom. Finishe ock bridge and O'. Mudded ho cement at surf	735! Sho and put d mudding dumped l le to top ace.	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole moff at 3118' cement at bot 250'. Set recement at 250 lo sacks of company of the sacks of the s	with chat to 3 Pulled pipe ttom. Finishe ock bridge and O'. Mudded ho cement at surf	735! Sho and put d mudding dumped l le to top ace.	t pipe 4 sacks of hole to 5 sacks of and put		
feet for each	Filled hole moff at 3118' cement at bot 250'. Set recement at 250 lo sacks of company of the sacks of the s	with chat to 3 Pulled pipe ttom. Finisher ock bridge and O'. Mudded ho cement at surf	735! Sho and put d mudding dumped l le to top ace.	t pipe 4 sacks of hole to 5 sacks of and put		



DRILLER'S LOG

Company: Derby Oil Company

NE ES ES

Sec. 23 Twp. 108 Rge. 21W

Farm: Pierce Wei Total Depth: 3748' Well Mo. 3

County: Graham,

Kansas

Comm: 5-13-51 Comp: 5-21-51 Contractor! Glenn W. Peel

Casing:

8 5/8" 250' cem. 4 1/2" 3745' cem.

Elevation:

Production:

Figures below indicate bottom of formations

Clay & Rock	0 - 40
Rock & Shells	250
Shale & Shells	1110
Sand & Shale	13 85
Shale, Red Bed & Shells	1635
Anhydrite	1680
Shale, Red Bed & Shells	2050
Shale & Shells	2320
Line & Shale	2460
Line	2680
Lime & Shale	2 8 50
Line	2 9 75
Shale w/lime streaks	3 225
Line	3300
Lime & Shale	3560
Lime	3645
Line & Shale	3700
Line	3748
Total Depth	3748

This is to certify that the above information is, to the best of our knowledge, true and correct.

GLEEN W. PEEL

A Company of the Comp	BI: Ifm Herfers
SUBSCRIEED AND SYCHN to before me this	23 Th day of May , 1951
My commission expires	Manaw M. Hekd



DOOK PAGE 149LINE 42