COPELAND Acid & Cement

TREATMENT REPORT

Acid Stage No. #1

Date 6/28/17 - 7-6-17 District Bridgeport F. O. No.
Company Ressler Well Services
Well Name & No. Manny Dodge #9 SWD
Location Field
County Knox State TX

Casing: Size 4½ Type & Wt. Set at ft.
Formation: Perf. to
Formation: Perf. to
Formation: Perf. to
Liner: Size Type & Wt. Top at ft. Bottom at ft.
Cemented: Yes / No. Perforated from ft. to ft.
Tubing: Size & Wt. Swung at ft.
Perforated from ft. to ft.

Open Hole Size T.D. ft. P.B. to ft.

Type Treatment:	Amt.	Type Fluid	Sand Size	Pounds of Sand
Bkdown	Bbl. /Gal.			
	Bbl. /Gal.			
	Bbl. /Gal.			
	Bbl. /Gal.			
Flush	Bbl. /Gal.			

Treated from ft. to ft. No. ft.
from ft. to ft. No. ft.
from ft. to ft. No. ft.

Actual Volume of Oil/Water to Load Hole: Bbl. /Ga
Pump Trucks. No. Used: Std. 323 St. Twin
Auxiliary Equipment Bulk 322
Packer: Set at f
Auxiliary Tools
Plugging or Sealing Materials: Type 85 cm 70 60-40-2 Gals.

Company Representative Treater Joey H

TIME a.m./p.m.	PRESSURES Tubing	PRESSURES Casing	Total Fluid Pumped	REMARKS
				6-28-17 Follow sand bail, dumped to plug off open hol
			7 BBls	25 sacks Cem, wash up going down 4½
			40 BBls	let fall last way out.
8:00				7-6-17
				On loc. TSA. Rig up
			0	Put hose in wind to 8⅝ start cement
			5 BBls	20 sacks 8⅝ slurry Full
				Tie in Tubing @ 800'
			0	Start mixing for down hole. 60-40-2 Poz 6 gel 5%
9:00			10 BBls	Good cement to surface, lay tubing down Strick hose
			12 BBls	in 4½ & Top off 2 BBls
				50 sacks cement slurry Full wash up in cellar.
				Wash up work string & Tools
				Plug out 9:00