WATER WELL RECORD	Form WWC-5	Division of Water Resources App. No.
1 LOCATION OF WATER WELL:	Fraction	Section Number Township No. Range Number
Country Pawnee	1/4 SW 1/4 NW 1/4 SW	1/4 12 T 22 S R 15 ☐E ☑W
Street/Rural Address of Well Location from nearest town or intersection: If a 1/4 South, 1 3/4 West of Radium	; if unknown, distance & direction towner's address, check here .	Global Positioning System (GPS) information: Latitude:
RR#, Street Address, Box #: 1331	tandish NW 80th Avenue d, Ks. 67576	Collection Method: ☐ GPS unit (Make/Model:
A DEPTH OF COMPLETED WELL 80 ft.		
TYPE OF SCREEN OR PERFORATIO Steel Stainless Steel Brass Galvanized Steel SCREEN OR PERFORATION OPENIT Continuous slot Mill slot Louvered shutter Key puncher SCREEN-PERFORATED INTERVAL	NMATERIAL: PVC None used (open hole) NGS ARE: Gauze wrapped Wire wrapped S: From. 80 ft. to	Int □ Drilled holes □ None (open hole) □ Other (specify) □ ft., From ft. to ft. Int., From ft. to ft.
6 GROUT MATERIAL: Neat cement Cement grout Bentonite Other Hole plug Grout Intervals: From ft. to ft., From ft. to ft., From 20 ft. to 0 ft.		
Grout Intervals: From	. toft., From	ock pens
0 4 Top soil		
4 26 Clay 26 80 Med sand & gravel/ streaks	few short clay	
7 CONTRACTOR'S OR LANDOWNER'S CERTIFICATION: This water well was constructed, reconstructed, or plugged under my jurisdiction and was completed on (mo/day/year) 11-14-11 and this record is true to the best of my knowledge and belief. Kansas Water Well Contractor's License No. 134. This Water Well Record was completed on (mo/day/year) 11-19-11 under the business name of Rosencrantz-Bemis by (signature) by (signature) Rosencrantz-Bemis Delay Please fill in blanks and check the correct answers. Send three copies INSTRUCTIONS: Use ty pewriter or ball point pen. PLEASE PRESS FIRMLY and PRINT clearly. Please fill in blanks and check the correct answers. Send three copies INSTRUCTIONS: Use ty pewriter or ball point pen. PLEASE PRESS FIRMLY and PRINT clearly. Section 1000 SW Jackson St., Suite 420, Topeka, Kansas 66612-1367.		
INSTRUCTIONS: Use typewriter or ball point pen. PLEASE PRESS FIRML and PRINT Clearly. Tease thin brained and instance of the production of		