

Notice: Fill out COMPLETELY and return to Conservation Division at the address below within 60 days from plugging date.

KANSAS CORPORATION COMMISSION OIL & GAS CONSERVATION DIVISION

1040818

Form CP-4

March 2009

Type or Print on this Form

Form must be Signed

All blanks must be Filled

WELL PLUGGING RECORD K.A.R. 82-3-117

OPERATOR: License #:			APIN	lo. 15 -			
OPERATOR: License #:				Spot Description:			
Address 1:				Sec ⁻			
Address 2:				Feet from			
City:	State:	Zip: +		Feet from East / West Line of Section			
Contact Person:			Foota	Footages Calculated from Nearest Outside Section Corner:			
Phone: ()				NE NW	SE SW		
ENHR Permit #:	Other: Gas Sto	SWD Permit #:	Coun Lease	County:			
s ACO-1 filed? Yes	_	log attached? Yes	│ No │ The p	The plugging proposal was approved on: (Date)			
Producing Formation(s): List A					(KCC District Agent's Name)		
	·	m: T.D	Plugg	Plugging Commenced:			
•	•	m: T.D	I Pluad	I Plugging Completed:			
Depth to	Top: Botto	m: T.D					
Show depth and thickness of a	all water, oil and gas forma	ations.	'				
Oil, Gas or Water Records			Casing Record (Surface, Conductor & Production)				
Formation	Content	Casing	Size	Setting Depth	Pulled Out		
Describe in detail the manner cement or other plugs were us		-			ods used in introducing it into the hole. If		
Plugging Contractor License #:			Name:				
Address 1:			Address 2:				
City:			State:				
Phone: ()							
Name of Party Responsible for	r Plugging Fees:						
State of	County, _		, SS.				
				Employee of Operator or	r Operator on above-described well,		

being first duly sworn on oath, says: That I have knowledge of the facts statements, and matters herein contained, and the log of the above-described well is as filed, and the same are true and correct, so help me God.

(Print Name)



TREATMENT REPORT

PIPE DATA PERFORMING PROPERTY TO THE STATE	energy ser	vices, LP							
State Post Post Post Post Post Post Post Post	Customer Date Date								
PIPE DATA PERFORMING PREMISE THE SUME Casing Size Washing Promper 125 Sacts 60/40Poz With Press ISIP Dopth Opeth From to 486 With Str. With Island Volume Volume From to 53 St Washing May 15 Min. Volume Press Washing Prom to 53 St Washing May 15 Min. Volume Press Washing Prom to Flow To Hard Sacts Water Total Lond Plug Doph Prom To Flow Drilling Mula & Ported Water Total Lond Coulomer Reprosorpation A run by uster Station Manager David Scott Caldidate Pressure Source United 9366 1993 19905 19326 19360 Division May 1990 1990 1990 1990 1990 1990 1990 199	Lease DAY 11/5 Well# 1-2 &								
PIPE DATA PERFORMING PREMISE THE SUME Casing Size Washing Promper 125 Sacts 60/40Poz With Press ISIP Dopth Opeth From to 486 With Str. With Island Volume Volume From to 53 St Washing May 15 Min. Volume Press Washing Prom to 53 St Washing May 15 Min. Volume Press Washing Prom to Flow To Hard Sacts Water Total Lond Plug Doph Prom To Flow Drilling Mula & Ported Water Total Lond Coulomer Reprosorpation A run by uster Station Manager David Scott Caldidate Pressure Source United 9366 1993 19905 19326 19360 Division May 1990 1990 1990 1990 1990 1990 1990 199	2083	ratt. Kansas	P炒 Drill ^o	outh County Barto	on State Cansas				
Casing Size Depth Depth Depth From To 4365 44 Lb/sh. C MY lafte SMin. Volume Volume Volume Volume Volume Volume Volume Volume To 4365 44 Lb/sh. C MY lafte SMin. Nav Press Max Press Press To 13 37 Lb/sd. 6 906 Lb/sh. T T 27 Lb T 12 Min. Is Min. Hill Used Annulus Vide From To 10 Station Manager Annulus Pressure Prom To Station Manager David Scott Coulomer Repressariable on A r mo ruster Service Units 9,366 19403 19905 19326 19360 Service Units 9,366 19403 19905 19326 19360 Differ Names: Massis; r Martial Min. Graw The Assis of Tubring	Týpe Job C. N. W }	Vy To Aband	on Forma	tion Legal I	Description - 15W				
Depth Perm to 480 14 Loss Central are 5 Min. Volume Volume From to 138 12 76 al. 6 90 Gents St. 1. 7 2 CO.F. T. 15 Min. Max Press 12 15 Min. Max Press 12 15 Min. Max Press 14 15 Min. Max Press 15 Mi	PIPE DATA	PERFORATING PATA	USED	SED TREATMENT RESUME					
Depth Scient To 48 G TO 15 St. C. MATTAIRE SM. Volume Volume From To 13 87 15 To 3 87 15 Mm. Max Press To 16 Mm. Max Press To 15 Mm. Max Press To 16	Casing Size Tuby Size	Shots Bipa 195	5actrs 60/40	POZ WITH PRESS	ISIP				
Max Press Prom To And Annulus Pressure	Depth Depth	م شار ا	14 Lb./s/r.	Max 1	5 Min.				
Wil Confidence of Annulus Prossure To Flush Drilling Mudal September Nation 10 From 10 Flush Drilling Mudal September Nation 10 Flush Drilling Mudal September Nation 10 Flush Drilling Mudal September Nation 10 Flush 19,860 Pumped Nations (Nation Nation 19,860 Pumped Nation Nation 10 Flush 19,860 Pumped Nation Nation 10 Flush 19,860 Pumped N	Volume Volume	From To 3.8	15/16al. 6.900	SaltsHITT DET	15 Min.				
Couser Representation of the Path Drilling Mudal Set Formers Water Total Lead Couser Representation of the Path Office Station Manager David Scott Contract R. Messicht Service Units 19,366 19,903 19,905 19,326 19,360 Diver Mannes Massicht Mattal Milk Graw Involved Pressure Pressure Bus Pumped Bate Service Log 10/100 Truckts on location and hold safety meeting. 15/100 35 Start Fresh Water Pre-Flysh. 150 36 Start Fresh Water Displacement. 150 36 Start Presh Water Displacement. 150 36 Start Drilling Mud Displacement. 150 36 Start Tresh Water Pre-Flysh. 250 Start Fresh Water Pre-Flysh. 250 Start Fresh Water Displacement. 100 20 Start Fresh Water Displacement. 117 175 Start Fresh Water Displacement. 117 175 Start Fresh Water Displacement. 118 Start Fresh Water Displacement. 119 Start Fresh Water Displacement. 110 20 Start Fresh Water Displacement. 110 20 Start Fresh Water Displacement. 1117 175 Start Fresh Water Displacement. 1118 Start Fresh Water Displacement. 1119 Start Fresh Water Displacement. 1110 20 Start Fresh Water Displacement. 1111 Start Fresh Water Displacement. 1111 Start Fresh Water Displacement. 1112 Start Fresh Water Displacement. 1113 Start Fresh Water Displacement. 1114 Start Fresh Water Displacement. 1115 Start Fresh Water Displacement. 1116 Start Fresh Water Displacement. 1117 Start Fresh Water Displacement. 1118 Start Fresh Water Displacement. 1119 Start Fresh Water Displacement. 1110 Start Fresh Water Displacement. 1111 Start Fresh Water Displacement. 1112 Start Fresh Water Displacement. 1113 Start Fresh Water Displacement. 1114 Start Fresh Water Displacement. 1115 Start Fresh Water Displacement. 1116 Start Fresh Water Displacement. 1117 Start Fresh Water Displacement. 1118 Start Fresh Water Displacement. 1118 Start	Max Press Max Press	Ftom To	Aug:	Avg	15 Min.				
Service Units 9,866 9,903 9,905 9,826 9,860		From To			Annulus Pressure				
Service Units 19,866 19,903 19,905 19,326 19,360 Private Massicht Mattail MM Graw Thomas Markey Book Primodel State Service Log 10:00 Tructiscon location and hold safety meeting. 13 Plug 3550 Feet - 25 sachs Cement Start Fresh Water Pre-Flush. 400 20 5 Start mixing cement. 150 36 5 Start Fresh Water Displacement. 150 36 5 Start Fresh Water Pre-Flush. 10:03 -0- 69 Start Mixing cement. 12:50 200 5 Start Mixing cement. 12:50 5 Start Fresh Water Displacement. 12:50 5 Start Fresh Water Displacement. 12:50 5 Start Mixing cement. 13:50 5 Start Mixing cement. 14 The Pluy Hofeet - 10 sachs cement. 15:50 5 Start Mixing cement. 15:50 5 Start Mixing cement. 15:50 5 Start Mixing cement. 16:50 5 Start Mixing cement. 17:50 5 Start Mixing cement. 18:50 5 Start Mixing cement. 19:50 5 Start Mixing cement. 10:50 5 Start Mi		·	Flush Drilling Ma	land water	<u> </u>				
Service Unite 19,866 19,903 19,905 19,826 19,860 Division Messeich Mattei Mille Graw Names Truck Sessing Tubing Pressure Blus Pumper. 10:00 Truck Son location and hold safety meeting. 15/Plug 3550 Feet - 25 sacks Cement 10:57 250 6 Start Fresh Water Pre-Flush. 150 36 5 Start Mixing cement. 150 36 5 Start Drilling Mud Displacement. 150 36 6 Start Drilling Mud Displacement. 150 36 5 Start Mixing Cement. 150 36 5 Start Fresh Water Pre-Flush. 250 200 5 Start Mixing cement. 12:50 5 Start Fresh Water Pre-Flush. 250 5 Start Fresh Water Pre-Flush. 250 5 Start Fresh Water Pre-Flush. 250 5 Start Fresh Water Displacement. 12:55 -0- 30 Start Fresh Water Displacement. 12:55 5 Start mixing cement. 12:55 Start mixing cement. 12:56 Start mixing cement. 12:57 Start mixing cement. 12:58 Start mixing cement. 12:58 Start mixing cement. 12:59 Start mixing cement. 12:50 S	Customer Representative	rmoruster Statio	n Manager David	ocott Credier rence	R. Messich				
Names It Sairt Tubling Pressure Plate Pressure P		903 19,905 19,8	26 19,860						
Timel of Pressure	Names 1 55(CT		1.Mr Graw						
15/Plug 3550Feet - 25 sachs Cement 10.57 250 6 Start Fresh Water Pre-Flush. 400 20 5 Start Mixing cement. 200 26 5 Start Mixing cement. 150 36 6 Start Drilling Mud Displacement. 150 36 6 Start Drilling Mud Displacement. 108 -0 - 69 Start Fresh Water Pre-Flush. 250 200 5 Start Fresh Water Pre-Flush. 250 10 5 Start Fresh Water Displacement. 100 20 5 Start Fresh Water Displacement. 1255 -0 - 30 Start Fresh Water Displacement. 177 175 Start mixing cement. 178 Start mixing cement. 120 5 Start Fresh water Displacement. 120 5 Start Mixing cement. 120 Start Mixing cement. 1	Time / / Pressure Pr	essure Bbls. Pumped.	Bate	Service Log					
1057 250 6 Start Fresh Water Pre-Flush. 400 20 5 Start Mixing cement. 200 26 5 Start Fresh Water Displacement. 150 36 6 Start Drilling Mud Displacement. 150 36 6 Start Drilling Mud Displacement. 150 36 6 Start Drilling Mud Displacement. 100 20 Start Fresh Water Pre-Flush. 250 10 5 Start Mixing cement. 100 20 5 Start Fresh Water Displacement. 1255 -0- 30 Start Fresh Water Displacement. 117 175 5 Start Fresh water Displacement. 120 -02 21 Start Fresh water Displacement. 214 Start Mixing Cement. 215 Start Mixing Cement. 216 Start Mixing Cement. 217 Start Mixing Cement. 218 Start Mixing Cement. 219 Start Mixing Cement. 219 Start Mixing Cement. 210 -0- 3 Start Mixing Cement.	10.00	Tructiso	n location an	a hold safety meet	ing.				
400 20 5 Start Mixing cement. 200 26 5 Start FreshWater Displacement. 150 36 6 Start Drilling Mud Displacement. 150 36 6 Start Drilling Mud Displacement. Stap pumping. 2nd Plug 1,070 Feet - 40 Sades Cement. 250 200 5 Start Fresh Water Pre-Flush. 250 5 Start Mixing cement. 100 20 5 Start Fresh Water Displacement. 117 175 5 Start Fresh Water Displacement. 120 -02 21 Start Fresh Water Displacement. 120 -02 21 Start Fresh Water Displacement. 130 -02 3 Start Fresh Water Displacement. 130 -02 21 Start Fresh Water Displacement. 214 -0- 3 Start Mixing cement. 215 Start Mixing cement. 216 -0- 3 Start Mixing cement. 217 Plug Policet Holosuch Surface Consists and push it down to Feet with Drill Pipe. 218 -0- 3 Start Mixing cement. 219 -0- 3 Start Mixing cement. 210 -0- 3 Start Mixing cement.			13/	ly 3550Feet - 2	5 Sacts Cement				
200 26 5 Start FreshWater Displacement. 150 36 6 Start Drilling Mud Displacement. 1108 -0- 69 Start Drilling Mud Displacement. 200 200 Start Fresh Water Pre-Flush. 250 0 Start Mixing Cement. 100 20 Start Fresh Water Displacement. 1255 -0- 30 Start Mixing Cement. 127 175 Start Mixing Cement. 100 20 Start Fresh Water Displacement. 100 20 Start Fresh Water Displacement. 120 Start Mixing Cement. 120 Start Fresh Water Displacement. 120 Start Fresh Water Displacement. 120 Start Fresh Water Displacement. 120 Start Mixing Cement. 120 Start Mixing Cement. 120 Start Mixing Cement. 214 Start Mixing Cement. 215 Start Mixing Cement. 216 Start Mixing Cement. 217 Start Mixing Cement. 218 Start Mixing Cement. 219 Start Mixing Cement. 210 Start Mixing Cement.	· · · · · · · · · · · · · · · · · · ·		6 sta	rt Fresh Water Pre	-Flush.				
150 36 b Start Drilling Mud Displacement. 108 -0- 69 Stop Pumping. 2"Plug 1,070 Feet - 40 Sacks Cement. 250 10 5 Start Fresh Water Pre-Flush. 250 10 5 Start Fresh Water Displacement. 100 20 5 Start Fresh Water Displacement. 1255 -0- 30 Stop pumping. 3"4" Plug 500 Feet - 80 Sacks cement. 175 5 Start mixing cement. 100 20 5 Start Fresh water Displacement. 120 -0- 21 Stop Pumping. 4" Plug 40 Feet 10 Sacks cement. Insert wooden plug into suitate casi in and push it down to Feet with Drill Pipe. 214 -0- 3 Start mixing cement. 250 -0- 3 Cement Circulated to surface Stop pumping. -0- 75 3 Plug Rat Hole.			5 Sta	rt Mixing cement.					
1250 -0- 69 Stop pumping. 2nd Plus 1. O 70 Feet - 40 Sacks Cement Start Fresh Water Pre-Flush. 250 10 5 Start Mixing Cement. 100 20 5 Start Fresh Water Displacement. 1255 -0- 30 Stop pumping. 3rd Plus 500 Feet - 80 Sacks Cement 127 175 Start mixing Cement. 120 -0- 21 Stop pumping. 4th Plus 40 Feet - 10 Sacks Cement Insert Wooden plus into Sufface Casing and push it down 40 Feet with Drill Pipe 214 -0- 3 Start mixing Cement. 250 -0- 3 Cement Circulated to Surface Stop pumping. Plus Rat Hole.		x00 _26	<u>5, Sta</u>	rt FreshWater Dis	placement.				
2 Sprimping. 2 Plug 1. O TO Feet - HO Sacks Cement 2 So 10 5 Start Fresh Water Pre-Flush. 2 So 10 5 Start Mixing cement. 100 20 5 Start Fresh Water Displacement. 12 So 5 Start Mixing cement. 12 So 5 Start Mixing cement. 17 175 5 Start Mixing cement. 100 20 5 Start Mixing cement. 100 20 5 Start Fresh water Displacement. 120 02 21 Start Fresh water Displacement. 130 130 130 Start Fresh water Displacement. 14 Plug Holeets 10 Sacks cement. 15 Insert Wooden plug into Surface Cassing and push it down to Feet with Drill Pipe. 214 0- 3 Start Mixing cement. 250 -0- 3 Cement Circulated to Surface Stoppumping. -0- 75 3 Plug Rat Hole.			6 Sta	ort Drilling Mud [Displacement.				
Start Fresh Water Pre-Flush. 250 0 5 Start Fresh Water Pre-Flush. 250 0 5 Start Fresh Water Displacement. 100 20 5 Start Fresh Water Displacement. 12:55 -0- 30 Start Fresh Water Displacement. 3 rd Plug 500 Feet - 80 Sacks cement 17 175 5 Start Mixing cement. 100 20 5 Start Fresh Water Displacement. 120 -0- 21 Stop pumping. 4 th Plug 40 Feet - 10 Sacks cement 1 nisert Wooden plug into suitale casing and push it down 40 Feet with Drill Pipe 2:14 -0- 3 Start Mixing cement. 2:50 -0- 3 Cement Circulated to Surface Stop pumping -0- 7:5 3 Plug Rat Hole.		0- 69	Sta		41 ~				
250 10 5 Start Mixing cement. 100 20 5 Start Fresh Water Displacement. 12:55 -0- 30 Stop pumping. 3rd Plug 500 Feet - 80 sacks cement. 175 5 Start Mixing cement. 100 20 5 Start Mixing cement. 100 20 5 Start Mixing cement. 120 5 Start Fresh water Displacement. 120 5 Start Mixing cement. 120 5 Start Mixing cement. 210 5 Start Mixing cement. 211 7 7 7 7 7 8 Start Mixing cement. 221 8 7 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8		Section 1 and 1 a	2,197		and the state of the second of				
12:55 -0- 30 Start Fresh Water Displacement. 12:55 -0- 30 Stop pumping. 3rd Plug 500 Feet - 80 sacks cement. 117 175 Start Mixing cement. 100 20 Start Fresh water Displacement. 120 -0- 21 Stop pumping. 4th Plug 40 Feet - 10 sacks cement. Insert wooden plug into surface casing and push it down to Feet with Drill Pipe. 214 -0- 3 Start Mixing cement. 250 -0- 3 Cement Circulated to surface Stop pumping. -0- 75 3 Plug Rat Hole.	12:50		5 5	ti i con moner i c	-t lush.				
12:55 -0- 30 Stop pumping. 3'd Plug 500 Feet - 80 sacks cement. 117 175 Start Mixing cement. 100 20 Start Fresh water Displacement. 120 -0- 21 Stop pumping. 4'M Plug 40 Feet - 10 sacks cement. Insert wooden plug into surface casing and push it down 40 Feet with Drill Pipe. 214 -0- 3 Start Mixing cement. 250 -0- 3 Cement Circulated to surface Stop pumping. -0- 75 3 Plug Rat Hole.		50 10	<u> </u>						
3rd Plug 500 Feet - 80 sacks cement 175 Start Mixing cement. 100 20 Start Fresh water Displacement. Stop pumping. 4 Tr Plug 40 Feet = 10 Sacks cement Insert wooden plug into surface casing and push it down 40 Feet with Drill Pipe 214 -0- 3 Start Mixing cement. Cement Circulated to surface Stop pumping -0- T.5 3 Plug Rat Hole.		00 00	<u>5 Sta</u>		placement.				
Start Mixing cement. 100 20 5 Start Fresh Water Displacement. 120 -0- 21 - Stop pumping. 4th Plug HOTeet-Alosachs scement. Insert Wooden plug into surface casing and push it down Hoteet with Drill Pipe. 214 -0- 3 Start mixing cement. 250 -0- 3 Cement Circulated to surface Stop pumping. -0- T5 3 Plug Rat Hole.	12.55	2- 1- 20 1	510	1 1 /					
Start Fresh water Displacement. Stop pumping. 4th Plug 40 Feet - 10 Suchs cement. Insert wooden plug into surface casing and push it down 40 Feet with Drill Pipe. 214 -0- 3 Start mixing cement. Cement Circulated to surface Stop pumping. -0- 75 3 Plug Rat Hole.			319) sacts cement.				
Stop pumping. 4 Ply 40 Feet all Sacts coment. Insert Wooden plug into surface casing and push it down 40 Feet with Drill Pipe. 2 14 -0- 3 Start mixing coment. 2 50 -0- 3 Cement Circulated to surface Stop pumping. -0- TS 3 Plug Rat Hole.									
4 Plus 40 Feet 30 South Scement Insert Wooden plug into suitaie casing and push it down 40 Feet with Drill Pipe 3 Start mixing cement 250 -0- 3 Cement Circulated to surface Stoppumping -0- [5] 3 Plus Rat Hole.	(2.5) 5 · · · · · · · · · · · · · · · · · ·	00 00			slacement.				
Insert wooden plug into surface casing and push it down 40 Feet with Drill Pipe 2 14 -0- 3 Start mixing cement. 2 50 -0- 3 Cement Circulated to surface Stoppumping -0- TS 3 Plug Rat Hole.	1 20								
2 14 -0- 3 Start mixing cement. 2 50 -0- 3 Cement Circulated to surface Stoppumping. -0- [5] 3 Plua Rat Hole.		基础。在IP的基础的一种基础。 在是其中的数据,因为中国的		支持 한 장소 重要 그 회장에 가고 있다. 그리죠? 그 전혀 되고 본 등을 이 속 모르게 그렇다.	and the control of th				
2:14 -0- 3 Start mixing cement. 2:50 -0- 3 Cement Circulated to surface Stop pumping. -0- 7:5 3 Plua Rat Hole.			4 ns	ert Wooden plug int	o Sufface Casing				
2:50 -0- 3 Cement Circulated to surface Stoppumping -0- [5] 3 Plua Rat Hole.					with Drill Tipe				
-0- T.5 3 Plua Rat Hole.					<u> </u>				
			Ceme	<u> </u>	tuce. Top pumping				
	10244 NE Hiway		• Pratt KS 67124-		ax (620) 672-5383				

10244 NE Hiway 61 • P.O. Box 8613 • Pratt, KS 67124-8613 • (620) 672-1201 • Fax (620) 672-5383