



BASICSM
ENERGY SERVICES
PRESSURE PUMPING & WIRELINE

10244 NE Hwy. 61
P.O. Box 8613
Pratt, Kansas 67124
Phone 620-672-1201

FIELD SERVICE TICKET
1718 09858 A

19-165-12W

DATE _____ TICKET NO. _____

DATE OF JOB 2-4-14		DISTRICT Pratt, Kansas		NEW WELL <input checked="" type="checkbox"/> OLD WELL <input type="checkbox"/> PROD <input type="checkbox"/> INJ <input type="checkbox"/> WDW <input type="checkbox"/> CUSTOMER ORDER NO.:					
CUSTOMER L. D. Drilling, Incorporated		LEASE DEM		WELL NO. 1-19					
ADDRESS		COUNTY Barton		STATE Kansas					
CITY		STATE		SERVICE CREW C. Messick; E. Masquez; J. Hanson					
AUTHORIZED BY		JOB TYPE: C.N.W. - Plug To Abandon							
EQUIPMENT#	HRS	EQUIPMENT#	HRS	EQUIPMENT#	HRS	TRUCK CALLED 2-4-14	DATE	AM	TIME
28,443	3								3:00
						ARRIVED AT JOB		PM	10:00
77,686-19,905	3					START OPERATION		PM	10:30
						FINISH OPERATION		AM	1:30
19,831-19,862	3					RELEASED	2-4-14	AM	1:45
						MILES FROM STATION TO WELL			75

CONTRACT CONDITIONS: (This contract must be signed before the job is commenced or merchandise is delivered).

The undersigned is authorized to execute this contract as an agent of the customer. As such, the undersigned agrees and acknowledges that this contract for services, materials, products, and/or supplies includes all of and only those terms and conditions appearing on the front and back of this document. No additional or substitute terms and/or conditions shall become a part of this contract without the written consent of an officer of Basic Energy Services LP.

SIGNED: *Jan Mill*
(WELL OWNER, OPERATOR, CONTRACTOR OR AGENT)

ITEM/PRICE REF. NO.	MATERIAL, EQUIPMENT AND SERVICES USED	UNIT	QUANTITY	UNIT PRICE	\$ AMOUNT
P CP 103	60/40 Pot	st	205		\$ 2460.00
P CC 200	Cement Gel	Lb	354		\$ 98 50
P CF 153	Wooden Plug, 8 5/8"	ea	1		\$ 160 00
P E 100	Pickup Mileage	mi	75		\$ 318 75
P E 101	Heavy Equipment Mileage	mi	150		\$ 1,050 00
P E 113	Bulk Delivery	tm	664		\$ 1,062 00
P CE 204	Cement Pump: 3,000 Feet To 4,000 Feet	hrs	4		\$ 2,160 00
P CE 240	Blending and Mixing Service	st	205		\$ 287 00
P S003	Service Supervisor	hrs	8		\$ 175 00

CHEMICAL / ACID DATA:			

SUB TOTAL		\$ 5820.94
SERVICE & EQUIPMENT	%TAX ON S	
MATERIALS	%TAX ON S	
TOTAL		

SERVICE REPRESENTATIVE: *Jan Mill*

THE ABOVE MATERIAL AND SERVICE ORDERED BY CUSTOMER AND RECEIVED BY: *Jan Mill*
(WELL OWNER OPERATOR CONTRACTOR OR AGENT)

FIELD SERVICE ORDER NO.

BASIC

energy services, L.P.

TREATMENT REPORT

Customer L.D. Drilling, Incorporated	Lease No. rated	Date 2-4-14
Lease DEM	Well # 1-19	
Field Order # 1858	Station Pratt, Kansas	County Barton
Type Job C.N.W. - Plug To Abandon	Formation 1/2 Drill Pipe	State Kansas
Legal Description 19-165-12W		

PIPE DATA		PERFORATING DATA		CEMENT USED		TREATMENT RESUME		
Casing Size 1 1/2" Drill Pipe	Shots/Ft 205	From 205	To sacs	60/40 Poz	With	RATE	PRESS	ISIP
Depth	From	To	48	Total	Get			5 Min.
Volume	From	To	13.8L	6.7 Gal., 6.92 Gal.	1/2 St., 1.4	3 CV. FT		10 Min.
Max Press 300 PSI	From	To						15 Min.
Well Connection X-Hole	Annulus Vol.	From	To			HHP Used		Annulus Pressure
Plug Depth	Packer Depth	From	To	Flush	Drilling mud and fresh water	Gas Volume		Total Load

Customer Representative Jim Michols	Station Manager Kevin Gordley	Treater Clarence R. Messich
Service Units 28,443	77,686	19,905
Driver Names Messich	Masquez	Hanson
19,831	19,862	

Time	Casing Pressure	Tubing Pressure	Bbls. Pumped	Rate	Service Log
10:00					Truckson location and hold safety meeting.
					1 st Plug 3,403 Feet - 50 sacks cement
10:27	300			5	Start Fresh water Pre-Flush.
		20		5	Start mixing cement.
		32		5	Start Fresh water Displacement.
	300	42		5	Start Drilling mud Displacement.
10:39	-0-	87			Stop pumping.
					2 nd Plug 870 Feet - 25 sacks cement
11:50	200			5	Start Fresh water Pre-Flush.
	200	7		5	Start mixing cement.
	200	13		5	Start Fresh water Displacement.
12:05	0	16			Stop pumping.
					3 rd Plug 480 Feet - 90 sacks cement.
					Start Fresh water Displacement
12:15	150			5	Start mixing cement.
	150	23		3	Start Fresh water Displacement.
12:23	-0-	25			Stop pumping.
					4 th Plug 40 Feet - 20 sacks cement.
					Push wooden Plug down with Drill pipe.
12:42	-0-			3	Start mixing cement.
12:45		5			Cement circulated to surface
	-0-	7		3	Plug Rat hole.