

[illegible]

TIME	PRESSURES		Total Fluid Pumped	REMARKS
	Tubing	Casing		
5:30		5.5"		On Location. Laying down collars.
				Hole 3188'
				Pipe-3186' Centralizers-1-3-5-7-9-43-46
				Baffle-3144' Baskets-2-44
				Port Collar-1280' JT# 45
				Land pipe and break circulation with mud pump. Circulate for 30 minutes
				Plug Rat Hole with 30sks 60/40poz
				Tie on 5.5" casing. Mix 50sks 60/40poz
				Mix 175sks 60/40poz 2% Gel,18% Salt,.5% C-37,.5% C41p, 5#/sk.
				Gilsonite.
				Displace with 76.7bbls at 6.75bpm-1000# Plug landed at 1300# Pressured
				up to 1600#
10:30				Released pressure. Float held
				Thank You!
				Nathan W.

[illegible]