



TREATMENT REPORT

Acid Stage No. *14705*

Date: *7/15/14* District: *...* F. O. No.
 Company: *...*
 Well Name & No.
 Location: Field:
 County: *Holan* State: *K*
 Casing: Size: *5 1/2* Type & Wt. Set at ft.
 Formation: Perf. to
 Formation: Perf. to
 Formation: Perf. to
 Liner: Size Type & Wt. Top at ft. Bottom at ft.
 Cemented: Yes/No. Perforated from ft. to ft.
 Tubing: Size & Wt. *2 1/4* Swung at: *12:00* ft.
 Perforated from ft. to ft.
 Open Hole Size T.D. ft. P.B. to ft.

Type Treatment: Amt. Type Fluid Sand Size Pounds of Sand
 Bkdown Bbl. /Gal.
 Bbl. /Gal.
 Bbl. /Gal.
 Bbl. /Gal.
 Flush Bbl. /Gal.
 Treated from ft. to ft. No. ft.
 from ft. to ft. No. ft.
 from ft. to ft. No. ft.
 Actual Volume of Oil/Water to Load Hole: *4885* Bbl. /Gal.
 Pump Trucks. No. Used: Std. *323* Sp. Twin
 Auxiliary Equipment *322 Bunk*
 Packer: Set at ft.
 Auxiliary Tools
 Plugging or Sealing Materials: Type *Sack Class A Cem*
250# Calcium Chloride (Gals.) (lb.)

Company Representative

Treater *...*

TIME a.m /p.m.	PRESSURES		Total Fluid Pumped	REMARKS
	Tubing	Casing		
<i>2:00</i>				<i>7/15/14</i>
<i>:</i>				<i>Start for location w/ tanks, Tank truck broke down</i>
<i>:</i>				<i>shaft call in to hardy about gas. Water had job before</i>
<i>:</i>				<i>call 7-16-14 return to you</i>
<i>:</i>				
<i>7:45</i>				<i>7-16-14</i>
<i>8:15</i>			<i>0</i>	<i>On loc JSA Dig up</i>
<i>8:20</i>			<i>488</i>	<i>11" @ 1300' tied off tubing start mud to load</i>
<i>:</i>			<i>0</i>	<i>Well broke circ</i>
<i>:</i>			<i>0</i>	<i>Start mix gas down hole 50 sack cement</i>
<i>:</i>			<i>988</i>	<i>50 sack cement washed up + down hole w/ mud</i>
<i>:</i>			<i>1588</i>	<i>bet cement fill rest of well</i>
<i>:</i>				<i>Pull tubing up to 950' mix 5 bags CC in 13 BBL</i>
<i>:</i>				<i>Water</i>
<i>8:40</i>			<i>0</i>	<i>Start mix gas down hole w/ hot pl.</i>
<i>8:50</i>			<i>1288</i>	<i>60 sack pl. and wash up down hole</i>
<i>8:55</i>			<i>1588</i>	<i>bet fill rest well help tank truck suck out pot</i>
<i>9:30</i>				<i>wash up Pull this out for the cement fill</i>
<i>9:45</i>				<i>Run in tubing top casing @ 1170'</i>
<i>:</i>				
<i>:</i>				<i>Pull tubing to 300'</i>
<i>10:00</i>			<i>0</i>	<i>Start mix gas down hole</i>
<i>10:15</i>			<i>2088</i>	<i>105 sack cement wash up to surface</i>
<i>10:30</i>				<i>Pull tubing top of surface</i>
<i>11:50</i>				<i>Wash up top down</i>