



# CEMENTING LOG

STAGE NO.

Date 3-5-15 District Dakkyks Ticket No. 62047  
 Company Beredco Rig Beredco 1  
 Lease Bailey 0E Well No. 2-27  
 County Frank State KS  
 Location 27-22N-34W Field \_\_\_\_\_

CEMENT DATA:  
 Spacer Type: \_\_\_\_\_  
 Amt. \_\_\_\_\_ Skys Yield \_\_\_\_\_ ft<sup>3</sup>/sk Density \_\_\_\_\_ PPG

CASING DATA: Conductor  PTA  Squeeze  Misc   
 Surface  Intermediate  Production  Liner   
 Size 5 1/2 Type New Weight 15.5 Collar \_\_\_\_\_

Bottom Stage  
 LEAD: Pump Time \_\_\_\_\_ hrs. Type Lite, ASC  
 Excess \_\_\_\_\_  
 Amt. 85/180 Skys Yield 10.9/6.57 ft<sup>3</sup>/sk Density 12.5/14.5 PPG  
 Pump Time \_\_\_\_\_ hrs. Type ASC  
 Amt. 300/50 Skys Yield 10.9/6.57 ft<sup>3</sup>/sk Density 12.5/14.5 PPG  
 WATER: Lead \_\_\_\_\_ gals/sk Tail \_\_\_\_\_ gals/sk Total \_\_\_\_\_ Bbls

Casing Depths: Top KB Bottom 4877'

Pump Trucks Used 435 Brandon  
 Bulk Equip. 818/287 - Wayne Meghaly  
891/310 - Lakene Winters

Drill Pipe: Size \_\_\_\_\_ Weight \_\_\_\_\_ Collars \_\_\_\_\_  
 Open Hole: Size 7 7/8 T.D. 4877' ft. P.B. to \_\_\_\_\_ ft.

Floater Equip: Manufacturer Weatherford 5 1/2  
 Shoe: Type APU Float Shoe Depth 4877'  
 Floater: Type Latchdown Flex Asc Depth 4834.50  
 Centralizers: Quantity 12 Plugs Top DVI Btm. Flex  
 Stage Collars DVI  
 Special Equip. 3 - Baskets  
 Disp. Fluid Type water/mud Amt. 112 Bbls. Weight \_\_\_\_\_ PPG  
 Mud Type 40 vis Weight \_\_\_\_\_ PPG

CAPACITY FACTORS:  
 Casing: Bbls/Lin. ft. 0.238 Lin. ft./Bbl. \_\_\_\_\_  
 Open Holes: Bbls/Lin. ft. \_\_\_\_\_ Lin. ft./Bbl. \_\_\_\_\_  
 Drill Pipe: Bbls/Lin. ft. \_\_\_\_\_ Lin. ft./Bbl. \_\_\_\_\_  
 Annulus: Bbls/Lin. ft. \_\_\_\_\_ Lin. ft./Bbl. \_\_\_\_\_  
 Perforations: From \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Amt. \_\_\_\_\_

COMPANY REPRESENTATIVE \_\_\_\_\_

CEMENTER Paul Beaumont

TIME	PRESSURES PSI		FLUID PUMPED DATA			REMARKS
	AM/PM	DRILL PIPE CASING	ANNULUS	TOTAL FLUID	Pumped Per Time Period	
			<u>Bottom Stage</u>			
						<u>Hold Safety meeting</u>
						<u>Run pipe float equip</u>
						<u>Drop ball, pumped ball through @ 500#</u>
						<u>circ 1 hr</u>
						<u>mix 85 skys Lite @ 12.5</u>
						<u>tail wt 180 skys Asc @ 14.5</u>
						<u>wash up to pit / release plug</u>
						<u>Displace w/ water</u>
						<u>Displace w/ mud</u>
						<u>plug did land float did hold</u>
						<u>Drop Dart opened fool @ 200#</u>
						<u>circ 3 hrs</u>
			<u>Top Stage</u>			
						<u>mix 30 skys in R.H</u>
						<u>mix 80 skys in M.H</u>
						<u>mix 250 skys Lite @ 12.5</u>
						<u>tail wt 50 skys Asc @ 14.5</u>
						<u>wash up to pit / release plug</u>
						<u>Displace w/ water</u>
						<u>plug did land fool did close</u>
						<u>betrust did circ</u>
						<u>Hold Safety meeting</u>

FINAL DISP. PRESS: 1000 PSI BUMP PLUG TO 1500 PSI BLEEDBACK 1/2 BBLs. THANK YOU