



TREATMENT REPORT

Acid Stage No. RT

Date: 6-30-11 District: Arpa F. O. No. _____
 Company: Passer Well Service
 Well Name & No: Atahy Dady #5
 Location: _____ Field: _____
 County: Revo State: Kc
 Casing: Size: 5 1/2 Type & Wt. _____ Set at _____ ft.
 Formation: _____ Perf. _____ to _____
 Formation: _____ Perf. _____ to _____
 Formation: _____ Perf. _____ to _____
 Liner: Size _____ Type & Wt. _____ Top at _____ ft. Bottom at _____ ft.
 Cemented: Yes/No. Perforated from _____ ft. to _____ ft.
 Tubing: Size & Wt. _____ Swung at _____ ft.
 Perforated from _____ ft. to _____ ft.
 Open Hole Size _____ T.D. _____ ft. P.B. to _____ ft.

Type Treatment: Amt. _____ Type Fluid _____ Band Size _____ Pounds of Salt _____
 Bkdwn. _____ Bbl./Gal. _____
 _____ Bbl./Gal. _____
 _____ Bbl./Gal. _____
 _____ Bbl./Gal. _____
 Flush _____ Bbl./Gal. _____
 Treated from _____ ft. to _____ ft. No. ft. _____
 from _____ ft. to _____ ft. No. ft. _____
 from _____ ft. to _____ ft. No. ft. _____
 Actual Volume of Oil/Water to Load Hole: _____ Bbl./Gal. _____
 Pump Trucks. No. Used: 223 Sp. _____ Twin _____
 Auxiliary Equipment: Rik 322
 Packer: _____ Set at _____
 Auxiliary Tools _____
 Plugging or Sealing Materials: Type: 90 sack Cem 45 sack G.O. H.O.

Company Representative _____

Treater Ray H

| TIME a.m./p.m. | PRESSURES | | Total Fluid Pumped | REMARKS |
|-------------------|-----------|--------|-----------------------|--|
| | Tubing | Casing | | |
| 12:00 | | | | On loc TSA Rig up mix 2 Bag C.C. in 6 Bbls water |
| : | | | | See 25 sack Hot plug tub @ 800' fluid 1800 down. |
| : | | | 0 | Start water to fill pipe up to 800' |
| : | | | 30 Bbls | Start mix Cem cement 6.3 sack to Bbl. go down hole |
| : | | | 9 1/2 Bbls | 30 sack only flush up gain down hole |
| 12:55 | | | | Let cement fall out, why did never break circulation |
| 1:45 | | | | Pull tub up to 250' |
| : | | | | Run sand line to 2000' never hit cement fluid 800' d |
| : | | | | Run tub back to 800' |
| : | | | 0 | Start mix gain down hole Cem come Add 100# Hulls. |
| 2:30 | | | 8 Bbls | 30 sacks Cem + Hulls amp no circulation Washup 13 Bbls |
| 2:35 | | | 9 1/2 Bbls | Let cement fall out. pull tub up to 250' |
| : | | | | Run sand line in Fluid 400' down. run sand line to 1600' |
| : | | | | never hit cement. Call for more Hulls. |
| : | | | | Run tub back to 800' Tie in tub |
| : | | | 0 | Start water to load. |
| : | | | 14 Bbls | 5 1/2 filled up Start mixy Hulls in water |
| : | | | | 200# in 10 Bbls water |
| : | | | 0 | Start Cem cement Add 50# more hulls. |
| 3:35 | | | 8 Bbls | 30 sacks away washup 1 Bbl let fall out |
| : | | | | Pull tub up to 250' |
| 4:10 | | | | Run sand line hit @ 500' Tie on tub @ 250' |
| : | | | 0 | Start mix gain down hole 6.3 sack Slurry |
| : | | | 9 Bbls | 45 sack only good cement up to surface of 5 1/2 |
| 5:30 | | | | Pull tub out top off 5 1/2 sand in |
| : | | | | Washup test down let fall |
| : | | | | Plug out 5:30 |