





TREATMENT REPORT

Acid Stage No. RT

Date: 6-29-17 District: Bulletin F. O. No. \_\_\_\_\_  
 Company: Bene Per  
 Well Name & No.: Callen Turner #1  
 Location: \_\_\_\_\_ Field: \_\_\_\_\_  
 County: Cowley State: Ko  
 Casing: Size 5 3/8 Type & Wt. \_\_\_\_\_ Set at \_\_\_\_\_ ft.  
 Formation: \_\_\_\_\_ Perf. \_\_\_\_\_ to \_\_\_\_\_ ft.  
 Formation: \_\_\_\_\_ Perf. \_\_\_\_\_ to \_\_\_\_\_ ft.  
 Formation: \_\_\_\_\_ Perf. \_\_\_\_\_ to \_\_\_\_\_ ft.  
 Liner: Size \_\_\_\_\_ Type & Wt. \_\_\_\_\_ Top at \_\_\_\_\_ ft. Bottom at \_\_\_\_\_ ft.  
 Cemented: Yes/No \_\_\_\_\_ Perforated from \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Tubing: Size & Wt. \_\_\_\_\_ Swung at \_\_\_\_\_ ft.  
 Perforated from \_\_\_\_\_ ft. to \_\_\_\_\_ ft.  
 Open Hole Size \_\_\_\_\_ T. I. \_\_\_\_\_ ft. P. B. to \_\_\_\_\_ ft.

Type Treatment: Amt. \_\_\_\_\_ Type Fluid \_\_\_\_\_ Sand Size \_\_\_\_\_ Pounds of Sand \_\_\_\_\_  
 Bkdown: \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 Flush: \_\_\_\_\_ Bbl./Gal. \_\_\_\_\_  
 Treated from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. No. ft. \_\_\_\_\_  
 from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. No. ft. \_\_\_\_\_  
 from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. No. ft. \_\_\_\_\_  
 Actual Volume of Oil/Water to Load Hole: \_\_\_\_\_ Bbl./Gal.  
 Pump Trucks: No. Used: Std. 323 Sp. \_\_\_\_\_ Twin \_\_\_\_\_  
 Auxiliary Equipment: Bulk 322 TT 133  
 Packer: \_\_\_\_\_ Set at \_\_\_\_\_ ft.  
 Auxiliary Tools: Poly Pipe  
 Plugging or Sealing Materials: Type: 95 sacks 60-40-2% Gal. \_\_\_\_\_ lb. \_\_\_\_\_

Company Representative \_\_\_\_\_ Treater: [Signature]

TIME a.m / p.m.	PRESSURES		Total Fluid Pumped	REMARKS
	Tubing	Casing		
3:40				USA rig up ground wireline truck. Has set CIBP 2310 going in w/ balls & 2 sacks - fluid 100' down
:			30 Bbl.	Start fill casing w/ water, peel 5 3/8 @ 250'
:				Take down wireline truck. Run poly in to 260'
:			5	Tie on start water, getting good blowdown surface
:			Green	Start mix going down hole 5 3/8 slurry
:			3 Bbl.	Break circ on 5 3/8 + 8 5/8 at same time
:			8 Bbl.	lost circ on 5 3/8 good circ on 8 5/8
:			12 Bbl.	Blew hole 1 poly no circ on 5 3/8 good circ on 8 5/8 - shut 8 5/8 off continue mix get circ on 5 3/8
:			15 Bbl.	Good cement on 5 3/8 pull poly out tie good on 5 3/8 open surface start mix going down hole
5:45			25 Bbl.	Good cement on 8 5/8 run 6 sack slurry Shut in 5 3/8 + surface
:				Wash up tools back up trucks
:				Run out 5:45 95 sacks
6:00				Left loc.