

BROOKS 1A8
Sec. 28 T. 23 R. 18

Started 11-24-62
Finished 12-15-62

The Joy was moved in on location and rigged up. Set 10' of 8" surface pipe and cemented it in with 3 sacks of cement.

2	Soil	2
6	Clay & Sand Rock	8
2	Shale	10
88	Lime	98
59	Shale	157
47	Lime	204
76	Shale	280
26	Lime	306
6	Shale	312
92	Lime Soft	404
159	Shale & Lima Shells	563
13	Lime	576
11	Shale & Lime Shells	587
15	Lime	602
13	Shale Sandy & Limey	615
30	Cored to	667
	Top of broken sand 650.50'	
	Show of oil @ 657'	
	Sand 659 - 663' Show of heavy oil	
	Ran drill pipe back to 434'. Hit tight hole. Ream hole to 480'.	
	Ream 4-3/4" hole to 7-7/8" from 637' to 667'	
3	Lime	670
12	Shale & Lime Shells	682
10	Lime	692
9	Shale, Limey	701
29	Lime	730
7	Shale, Limey	737
10	Lime	747
8	Shale, Limey	755
5	Lime	760
5	Shale	765
21	Core to	786
	Lost 9' of core	
	Ream the hole and catch 5' samples in core hole.	
	Drilled new hole from 786' to 836' and catch 5' samples	
48	Core to	884
51	Core to	935
	Full recovery	
	Reamed hole with 7-7/8" bit from 836 to 935'. Catch samples every 5'.	
	Sample #16 CR through #34 CR	
28	Cored to	963
	Caught samples from 935 to 963'. Drilled new hole from 963 to 1005'.	
50	Cored to	1055
50	Cored to	1105
	Reamed the hole from 1005 to 1045'	
	Catching 5' samples	
	Reamed the hole from 1045 to 1105'	
20	Cored to	1125
	Lost 1.10'	
	Reamed the core hole 1105 to 1125'	
33	Catch samples of new hole from 1127' through 1160'.	
	Show of Lime at 1154.70'	
23	Catch 5' samples 1160 to 1183	
	Reamed the hole Lime 1173 to 1182'.	
	Reamed the hole 1173 to 1199' with 6 1/4" bit	
	Drilled to	1221.41

Mack C. Colt:

No API #

Colt Energy's

API # 15-001-03208

Same "Brooks" 1-A0 Well

Catch 5 foot samples 600-605; 610-615;
615-620; 620-625; 625-630; 630-635; 635-637

Catch samples every 5' to 1225'
Bit wore out.