TO:	API Number: 15-141-20,326 ~00-	- 60
TO: STATE CORPORATION COMMISSION 9-25		
CONSERVATION DIVISION - PLUGGING	<u>S2 S2 SW</u> /4 SEC. <u>29 , 09 S, <u>1</u></u>	2 W
130 SOUTH MARKET, SUITE 2078	feet from S section lin	ne
WICHITA, KANSAS 67202	feet from E section lin	ne
Operator license# 5056	Lease: Kendig Well # 1	_
Operator: F.G. Holl Company	County: Osborne //4	4.40
Address: P.O. Box 780167-6427 E. Kellogg #1	Well total depth 3520	feet
Wichita, Kansas 67278-0167	Conductor Pipe: 0 inch @ 0	feet
Elwyn Nagel	Surface pipe 8 5/8 Inch @ 215	
Aband. oil well, Gas well, Input well	_, SWD, D & A_X	
Plugging contractor: Shields Drilling Co., Inc.	License# 5184	_
Address: Russell, Kansas 67665		
Company to plug at: Hour: P.M. Day: 25 Mont	h: September Year: 1996	
Plugging proposal received from: Bert Beery		
Company: Shields Drilling Co., Inc.	Phone: 316-684-8481	
11 0 F/08 04F1 0 B 1/4F0 C0/40 m		
Were: 8 5/8" - 215' S.P. cwc. w/150 sxs 60/40 p		
Elv. 1944' - Anhy. 1072'- Mud condition 44 vis.		
problems. Proposal 200 sxs 60/40 pozmix - 6% gel		arill
stem, circulated hole - 40 to 45 vis mud - heav		-1-1-
25 sxs at 1080' - 100 sxs at 840' - 40 sxs at	: 270 - 10 SXS at 40 . 15 SXS in rate	erore
(circulate) - 10 sxs mousehole.		
		
Plugging Proposal Received by: Marion J. Schm	idt .	
Plugging operations attended by agent? All[
Completed: Hour: 7:00 P.M. , Day: 25 ,		
	Month: September , Year:,	1996
	a particular and the second se	
Actual plugging report: Shields Oil ordered 200		ocele
per sack. Spotted and displaced all cement thr	sxs 60/40 pozmix - 6% gel and 174# floor cough drill pipe with heavy mud Between	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck.	sxs 60/40 pozmix - 6% gel and 17/4#f10	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement.	sxs 60/40 pozmix - 6% gel and 17/4 11 11 11 11 11 11 11 11 11 11 11 11 11	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement.	sxs 60/40 pozmix - 6% gel and 174# florough drill pipe with heavy mud Between State Confidence of the	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement.	sxs 60/40 pozmix - 6% gel and 174# florough drill pipe with heavy mud Between State Confidence of the	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement.	sxs 60/40 pozmix - 6% gel and 174# f10 rough drill pipe with heavy mud Between	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement.	sxs 60/40 pozmix - 6% gel and 174# f10 rough drill pipe with heavy mud Between	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement. 15 sxs in rathole (circulated) - 10 sxs in mou	sxs 60/40 pozmix - 6% gel and 174# f10 rough drill pipe with heavy mud Between	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement. 15 sxs in rathole (circulated) - 10 sxs in mount. Remarks: Cemented by Allied Cement.	sxs 60/40 pozmix - 6% gel and 174#florough drill pipe with heavy mud Between School Sc	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement. 15 sxs in rathole (circulated) - 10 sxs in mount in	sxs 60/40 pozmix - 6% gel and 174# florough drill pipe with heavy mud Between cough dr	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement. 15 sxs in rathole (circulated) - 10 sxs in mount in	sxs 60/40 pozmix - 6% gel and 174# £10 rough drill pipe with heavy mud Between	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement. 15 sxs in rathole (circulated) - 10 sxs in mount in	sxs 60/40 pozmix - 6% gel and 174# florough drill pipe with heavy mud Between cough dr	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement. 15 sxs in rathole (circulated) - 10 sxs in mount in	sxs 60/40 pozmix - 6% gel and 174# florough drill pipe with heavy mud Between cough dr	ocele
per sack. Spotted and displaced all cement the plugs. Pumped in with pump truck. 1st. Plug at 1080' w/25 sxs. cement. 2nd. Plug at 840' w/100 sxs. cement. 3rd. Plug at 270' w/40 sxs. cement. 4th. Plug at 40' w/10 sxs. cement. 15 sxs in rathole (circulated) - 10 sxs in mount in	sxs 60/40 pozmix - 6% gel and 174# florough drill pipe with heavy mud Between cough dr	GL